

# GFBBox 14

## Alkaline washing/cleaning detergent for transport boxes

concentrate

### Product properties

- suitable for both automatic and manual wash

GFBBox 14 is intended for the washing of transport boxes used in the food industry both by machine and by hand. The ingredients in the product ensure the effective removal of markings glued on boxes.

### Ingredients

sodium hydroxide, sodium metasilicate, potassium hydroxide, EDTA.

### Usage

Machine wash – follow the instructions given by manufacturer.

Manual wash – rinse the surface first with lukewarm water. Then make 0,25-2% working solution and spray the solution onto the surface, allow to take effect for 10 to 15 minutes. Rinse the dirt off with hot water.

### Working solution concentrations and exposure times

0,25-2%	2,5-20ml/l	10-15 min
---------	------------	-----------

### Warning

Causes severe skin burns and eye damage. Harmful if swallowed. Do not breathe mist/vapours/spray. Wear protective gloves/protective clothing/ eye protection/ face protection.

### Physical-chemical properties

Physical appearance: *yellow liquid*

pH: ~13

Solubility: *completely soluble in water*

Relative density: *1,23 g/cm<sup>3</sup>*

### Storage

See the best before date on the package. Store at temperature over +10°C, keep away from direct sunlight.

### Package

25L canister (30,75kg)

200L vat (246 kg)

1000L IBC container (1230 kg)

