

# OVEN CLEANER

## Strong alkaline foam cleaner for smoke ovens

concentrate

### Product properties

- removes grease effectively
- removes resistant soot, grease and scorched scrap
- not suitable for light metal surfaces

Oven Cleaner is intended for the washing of smoke ovens, frying-pans, griddles, BBQ devices and other heavily soiled and greasy surfaces in the food industry and industrial kitchens.

### Ingredients

sodium hydroxide, surfactants, foam stabilizers, complexing agents.

### Usage

Remove the loose dirt from surface if possible. Make a working solution. Use foam machine, spray bottle or a brush to apply solution onto the surface and allow to take effect for 10-15min. Rinse the dirt and foam off with hot (55°C) water.

Cleaning foam suits perfectly for use in industrial smoke ovens integrated washing machines.

**NB!** Not suitable for light metal surfaces!

### Working solution concentrations and exposure times

2 – 10%	20-100ml/l	10-15min
---------	------------	----------

### Warning

Causes severe skin burns and eye damage. Do not breathe vapours/spray. Wear protective gloves/ protective clothing/ eye protection/ face protection.

### Physical-chemical properties

Physical appearance: *yellow liquid*

pH: *ca 13*

Solubility: *completely soluble in water*

Density: *1,4 g/cm<sup>3</sup> (20°C)*

Other info: *Reacts to acids.*

### Storage

See the best before date on the package. Store at temperatures over 10-20°C, keep away from direct sunlight.

### Package

25L canister (35kg)

200L vat (280kg)

1000L IBC container (1400kg)

