

VITASEPT[®]WIPES

Alcohol-based disinfecting wipes

Product properties

- aldehyde- and chlorine-free
- odorant- and colorant-free
- quick exposure time (30 sec)
- doesn't leave residue
- soft fabric-like material

Vitasept[®]Wipes are meant for the disinfection of alcohol resistant surfaces. Soft wipes are permeated with a wide-spectrum disinfectant and they do not leave residues on surfaces after use, being thus ideally suitable for disinfecting such surfaces that come into contact with food and food products.

Ingredients

isopropanol 60%, ethanol (denat.) 15%

Spectrum of efficacy

Bacteria: *E.coli*, *Salmonella spp.*, *Staphylococcus spp* (MRSA), *Streptococcus spp*, *Listeria spp*, *Enterococcus faecalis*, *Acinetobacter baumannii*, *Corynebacterium ammoniagenes*, *Mycoplasma spp*, *Pseudomonas aeruginosa*, *Enterobacter aerogenes*, *Klebsiella pneumoniae*, *Serratia marcescens*, *Shigella dysenteriae*, *Vibrio cholerae*, *Bacillus cereus*, *Mycobacterium*, *Clostridium spp* etc

Viruses: HBV, HCV, HIV, adeno, rota, influenza virus (including swine flu) etc

Fungi: *Candida albicans*

Exposure time

Surface disinfection 30 seconds.

Usage

Pull the wipes out until perforated spot according to the amount necessary and if needed support with other hand in order to tear away. All surfaces should be wiped with Vitasept[®]Wipes, make sure that the surface is covered with disinfectant. Throw the used

wipe away. In order to avoid the drying of wipes, close the flip.

Warning

Highly flammable liquid and vapour. Causes serious eye irritation. May cause drowsiness or dizziness. Keep out of reach of children. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Keep container tightly closed. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention.

Physical-chemical properties

Physical appearance: *white damp wipes, permeated with colourless, clear liquid*

Scent: *distinctive (alcohol)*

pH: *6.0 – 7.0*

Density (liquid): *0,84 – 0,87 g/cm³ (20°C)*

Storage

See the best before date on the package. Store at temperatures 5-25°C, keep away from direct sunlight.

Conformity to standards

EN 13727, EN 14348, EN 13624, EN 14476

Other test methods

RKI/DVV

Package

120 wipes in a can, dimensions of a wipe 20 x 20cm
450 wipes in a bucket, dimensions of a wipe 18 x 20cm