

# GFC 14

## Universal alkaline cleaning detergent for cleaning surfaces, devices and transport boxes

*concentrate*

### Product properties

- foaming cleaning agent
- effective ingredients
- assures the cleanliness even at hard-to-reach places

GFC 14 is intended for cleaning highly soiled surfaces and devices. With its foaming properties the detergent is suitable for cleaning both vertical and horizontal surfaces. The effective ingredients in the product ensure that the product also functions in hard-to-reach places.

Excellent detergent for the washing of smoke ovens, frying-pans, griddles, BBQ devices and other heavily soiled and greasy surfaces in the food industry and industrial kitchens.

Effective solution for removing biofilm with slimy structure and for manual washing of transport boxes. The ingredients in the product ensure the effective removal of markings glued on boxes.

### Ingredients

sodium hydroxide, sodium metasilicate, potassium hydroxide, EDTA, foam stabilizers, complexing agents

### Usage

Rinse the surface with lukewarm water. Make a 0,25-10% working solution and use a spray bottle to apply solution onto the surface and allow to take effect 10-30 minutes. Rinse the dirt off with hot water.

**NB!** Not suitable for light metal surfaces.

### Working solution concentrations and exposure times

0,25-10%	2,5-100ml/l	10-30 min
----------	-------------	-----------

### Warning

Causes severe skin burns and eye damage. Harmful if swallowed. Do not breathe mist/vapours/spray. Wear protective gloves/ protective clothing/ eye protection/ face protection.

### Physical-chemical properties

Physical appearance: *yellow liquid*

pH: *~13*

Solubility: *completely soluble in water*

Relative density: *1,23 g/cm<sup>3</sup>*

### Storage

See the best before date on the package. Store at temperature over +10°C, keep away from direct sunlight.

### Package

25L canister (30,75kg)

200L vat (246 kg)

1000L IBC container (1230 kg)

